Xplore CB Pro conveyor belt pro

A high quality add-on for the Xplore Micro compounders





Accessories for formulation development: reliable, reproducible and fast R&D results

The Xplore conveyor belt pro (CB Pro) is specially designed to be used to support and guide polymer strands directly from a smaller extruder or compounder die. The CB Pro does fit perfectly to our MC 5 and MC 15 compounders. The belt speed of the CB Pro is adjustable, allowing it to be precisely tailored to each individual processing application.

Instead of being conventionally extruded into a water bath, the polymer strand is extruded directly onto a non-sticking PTFE conveyor belt, which carefully, in a controlled manner, draws the fragile nascent strand away from the die opening. This controlled drawing of the strands, while they are still in a non-solid state, prevents breaks or cracks in the strands. This enables the polymer strand to cool down in a predetermined shape ready for a subsequent analyzing step or to be directly fed into a small pelletizer.

Optionally a transparent tunnel-shaped hood can be placed onto the CB pro, where, via a purge port an inert gas can be introduced to create an oxygen free environment to minimize degradation of the strand.



Benefits:

- Large operating window
- Prolonged draw rates possibleTemperature resistant PTFE belt
- Easily exchangeable belt
- Gentle, straight-line strand cool down avoids strand breaks for a subsequent analyzing or pelletizing step
- Can be retrofitted into existing extrusion lines







CB Pro

Technical Specifications:

CB Pro:

- Non-sticking PTFE belt,
- Belt width and usable length: 6×70 cm
- Digital indexed readout of belt speed
- Speed range: 10 250; other speed ranges on request
- Overall dimensions (h x w x l): 15 x 11 x 82 cm
- -Weight II kg
- -115/230V 50/60 Hz

Xplore Instruments BVArendstraat 5

6135 KT, Sittard The Netherlands

Tel: +31 46 208 97 70 Fax: +31 46 208 97 71

info@xplore-together.com www.xplore-together.com

Trade Register: 60040114